


Installation Guideline




Chair

Components



Easy 4 Step Assembly




STEP 1

Press the Castor (wheel) pin against the holes in the base bottom and fit them tight to the base.

Fit all 5 castors one by one.


Place the gas-lift cylinder in the center hole of the base in the shown direction in the image



STEP 2

Ensure the gas-lift is in place, properly fit to the base.

Avoid pressing the gas-lift from the top knob.



STEP 3

Invert the chair back/seat assembly to see the mechanism fitted at the bottom of the seat. Insert the top of the Gas-lift into the hole located at the center of the mechanism.



STEP 4

Keep the chair upright and press the chair at the center of the seat to ensure final assembly. Chair is ready to be used.



E-mail us at: response@hni-india.com Find us at: www.estore.hni-india.com